




VISOCALL IP. Connection Module SM.

User Manual.

HEALTH CARE

SCHRACK
S E C O N E T

Connection Module SM.



Diagnostic socket ①
(5 pin DIN)

Socket for patient terminal ②
(RJ45)

Socket for optional
laptop (RJ45) ③

CAUTION: It must be checked that the patient terminal is fully functional each time the patient terminal is plugged in and each time a disconnection call is reset. It must be checked the fully functional each time a device is plugged in the diagnostic socket!

Diagnostic socket (1)

The diagnostic socket, a 5 pin DIN socket, is used to connect a medical device (monitor, injection pump, ...) which must conform to EN60601 or a VISOCALL IP system radio receiver.

Other devices, e.g. contact mats or similar may only be connected in conjunction with the VISOCALL IP system diagnostic adapter AD-DIA.

Socket for patient terminal (2)


This socket is solely intended for connecting a patient terminal of type PAT / PAT-E / PAT-L or a push button BT-IP. Neither a laptop nor any other kind of PC-similar device may be connected here.

All patient handsets are fitted with self-ejecting connector plugs. The unintentional removal of the device auto-matically triggers a so-called disconnection call.

Socket for notebook (3)

You can connect your laptop here.
For safety reasons this is only permissible if your laptop is working in battery mode, and is not plugged in (230V~).

Auto-disconnecting socket



The device plugs are designed in such a way, that in the event of the the cable being pulled improperly, then the connector plug is ejected from the socket, regardless of its position (see sketch below) This prevents the cable, the connector plug itself and the socket from being broken. A so-called “disconnection call” is generated in the system. It is possible to reconnect the connector plug at any time.



Cleaning and Disinfection

For the SM connection module, without exception only use disinfectants that do not contain ketones or esters either in part or in full.

For the disinfection process disinfection by wiping should be used – and under no circumstances a disinfection by submersion process.

Operation and Maintenance

Operation of the VISOCALL IP call system is subject to the conditions of article 9 of the standard DIN VDE0834 part 1. We would therefore take this opportunity to point out that this article requires among things that periodical inspections and maintenance are carried out, which we will gladly carry out on your behalf.



SCHRACK SECONET AG

Eibesbrunnnergasse 18
A-1120 Vienna
Tel. +43 1 81157
office@schrack-seconet.com
www.schrack-seconet.com

EN

Czech Rep. • CZ-149 00 Prague 4 - Újezd., Štítová 283 • Tel. +420 2 74784422
Hungary • HU-1119 Budapest, Fehérvári út 89-95 • Tel. +36 1 4644300
India • IN-122002 Gurgaon, DLF Golf Course Road, Sector-54 • Tel. +91 124 4141501
Poland • PL-02-672 Warsaw, ul. Domaniewska 44a, bud. Platinum V • Tel. +48 22 3300620
Romania • RO-023961 Bucharest, Str. Mântuleasa nr. 15A et. 1, Sector 2 • Tel. +40 372 756316
Russia • RU-129626 Moscow, Ul. Staroalexejevskaja 5 • Tel. +7 495 5105015
Slovakia • SK-83527 Bratislava-Rača, Mudrochova 2 • Tel. +421 2 44635595
Sweden • SE-145 84 Norsborg, Botvid Business Center • Tel. +46 8 6801860
Turkey • TR-34722 Kadıköy-İstanbul, Kasap İsmail Sk. 5/5 • Tel. +90 216 3455199

HEALTH CARE

SCHRACK
S E C O N E T